





SERVICE MANUAL

Hydraulic Brakes type LB/288..., LBS/V]/289 and
LBS[V]/290 - series 4
Euro and SAE versions









Instructions in this manual are for brakes type LB...

Cleanliness is extremely important when repairing these brakes. Work in clean area!

Before disassembly, drain oil from brake.

If there is castellated nut, washer or key, they have to be removed from the shaft.

Although not all drawings show the brakes in disassembly devise, we recommend that you keep brake clamped during disassembly.

For LBS[V]/289 and LBS[V]/290:

1. Unscrew plugs (3 pcs. for LB/288 and LBS, 4 pcs. for LBV) using S6 Allen head spanner and set them in order aside incl. seals.




Fig.1

2. Place the brake in disassembly devise (plate with central hole ø83 for LB/288, 289 or ø125 (ø127) for LBS(LBV)/290 with two pins opposite staved into it) with the output shaft directed downwards. Unscrew screws (8 pcs.) using Allen head spanner.

Note: Unscrew the screws uniformly, diametrically, successively to prevent breaking the screw heads in result of the spring pressure.

Remove flange incl. shaft seal and outer rim of bearing (see Fig. 1).

3. Remove from flange shaft seal. Do not dismount outer rim of bearing from flange.




Fig. 2

4. Remove piston from housing. Use special tool with two screws M5x20 screwed in M5 holes to rest in advance and using a puller. Take the O-rings and the Back up rings out of piston and bushing grooves. The piston will come out with inner rim of bearing, adjustment washer and dick springs (see Fig.2).

5. Remove from housing groove O-ring 114,2x1,78.




Fig. 3

6. Take the O-ring 109,5x3 and the Back up ring 109x114,2x1,4 out of housing groove (see Fig.3).

7. Remove bushing carefully out of the brake housing using a puller with slight swivelling motions. Remove from bushing groove O-ring 71x3 and Back up ring 71x76,2x1,4.

8. Take the O-ring 109,5x3 and the Back up ring 109x114,2x1,4 out of housing groove (see Fig.3).

9. Remove from housing whole assembly contained shaft, inner rims of front ant rear bearings, steel disks, sinter disks and support rings (see Fig.4). Separate the rims from shaft. Check the friction elements for defects (availability of wearing marks and checking the weight) and replace with new ones.




Fig.4

10. With a small screwdriver remove dust seal from housing.

Knock the shaft seal out of housing using a soft bushing and a plastic hammer (see Fig. 5). Do not remove from housing outer bearing rim!




Fig. 5

Seal Kits:

Euro version

SK 41 5127 8032 for LB/288-series 4

SK 41 5127 8000 for LBS[V]/289 and LBS[V]/290 - series 4

SAE version

SK 41 5128 9500 for LB/288 - series 4

SK 41 5128 9544 for LBS/289 and LBS/290 - series 4

SK 41 5128 9619 for LBV/289 and LBV/290 - series 4

1. CLEANING:

Wash all parts (except seals) in a weak solvent on carbon base and then degrease.

2. MEASURING AND REPLACEMENT:

Measure all parts and compare their actual dimensions with the nominal ones given in the technical documentation. Replace any parts with scratches or burrs that could cause leakage or damage with new ones. Use new seals and washers when reassembling the motor.

3. LUBRICATION:

Lubricate all friction parts, which should be reassembled with light film of petroleum jelly.

1. Place lubricated shaft seal (5 bar) in the housing and firmly push with Seal driver (see Fig.6).




Fig.6

2. If dismounted, stave the outer bearing rim of the front tapered bearing into the housing (with the bigger diameter orientated to the housing) using a bushing made from non-ferrous metal (bronze, brass) and sizes $\phi 55 \times 61 \times 50$ and a 2000daN press. Fix the housing in reassembly devise (plate with an $\phi 83$ hole for LBS[V]/289 or $\phi 125$ ($\phi 127$) for LBS[V]/290 and two pins on $\phi 106$).

3. Stave to the rest over the front part of shaft the inner bearing race and the roller retaining ring of the front tapered roller bearing. Use a small press and an $\phi 36 \times 42 \times 90$ bushing. Arrange correct the sinter disks beginning and finishing with the steel disk and engaging the sinter disks inner teeth with the shaft outer teeth. Place support disks over friction pack. See Table 1 for correct number of disks.

Place a slightly oiled safety metal cap (for protecting the shaft seal ring lips) on the assembled shaft. Mount carefully the shaft assembly into the housing to the rest!

ATTENTION: Before mounting grease well each friction disk. The external 3 teeth of all steel disks should coincide with the grooves milled in the housing!

4. Mount lubricated O-ring 109x114,2x1,4 (2 pcs.) with back up ring 109,5x3 (2 pcs.) into housing grooves. (see fig.7)

ATTENTION: Orient O-ring to the arch sector of back-up ring.

9. Mount lubricated O-ring 71x3 with back up ring 71x76,2x1,4 into bushing grooves. (see Fig.7)




Fig.7

10. Assemble together the lubricated piston and bushing. Mount assembly in brake housing using a hand-power press with guaranteed rectilinear movement.




Fig.8

11. Install adjustment washer and disk springs (see Fig. 8).

IMPORTANT! The size of adjustment washer should ensure opening pressure as shown in Table 1 (after mounting of flange the dimension over disk springs should be $9 \pm 0,1$ mm) (see Fig.8).

12. On rear part of shaft stave the inner bearing race of the rear bearing incl. the roller retaining ring. Outer rim is staved in flange.

13. Lubricate and install O-ring 114,2x1,78 in the housing seal groove.

14. Lubricate slightly the internal surface of the flange and orient it as follows:

- drain port in flange should be rotated 11° left of release port in housing (see Fig.1).
- line up the bolt holes of housing and flange.

15. Mount flange to housing with 8 screws M8 and alternately torque them to 2,5÷3,0 daNm using S6 Allen head spanner (see Fig.1).

ATTENTION: The axial clearance between front and rear tapered bearing should be $0,04\pm0,1$ mm. It can be realized by decreasing the flange thickness.

16. Install seal on plug and torque to 2,5÷3,0 daNm using S6 Allen head spanner (see Fig.1). For LBS plugs are 3 pcs. and for LBV – 4 pcs.

17. Lubricate flange seal groove and external surface of shaft. Place lubricated shaft seal (high pressure) in the flange and firmly push with Seal driver.

18. Reposition brake assembly with output shaft up. Lubricate dust seal and install in housing seal groove.

19. Install key in shaft key groove. For cone shafts install washer and screw castellated nut.

Disassembly and reassembly of LB/288:

Follow the same disassembly and reassembly procedures as for LBS[V]/289 and LBS[V]/290 except following:

Disassembly:

1. The plugs are mounted in housing, not in flange.




Fig. 9

2. Separate O-ring 82x2 from flange (see Fig.9). There are no rear bearing and shaft seal.

3. After dismounting of piston and bushing turn the brake unit with open side downwards. Shake it slightly on soft surface. Support rings, sinter disks and steel disks will drop out.

4. Reposition brake with output shaft up.




Fig. 10

Remove from housing shaft seal (see Fig.10).

Remove the retaining rings using utility pliers for holes and shaft.

5. Place the brake in disassembly devise (plate with central hole ø83 with two pins opposite staved into it) with the output shaft directed downwards. Separate shaft from housing using a small press. Remove bearing from shaft.

Reassembly:

6. Using a small press and bushing made from non-ferrous metal (bronze, brass) stave to rest the radial bearing over the front part of shaft.

Mount the retaining ring in shaft in front of the bearing (see Fig.10).

7. With a small press stave the assembled shaft in front part of the housing. Mount the retaining ring in housing (in front of the bearing). Note: The retaining rings are correct mounted when could be rotated over shaft axes.

8. Place a safety cap over the shaft journal to protect the seal lips against breaking. With seal driver stave in the housing shaft seal (see Fig.11).




Fig. 11

9. Turn the housing and place it in an assembling fixture (plate with a central hole ø83 and two pins of ø106 diametrically). Arrange the steel and sinter disks successively in the housing along the shaft teeth.


10. After mounting the flange to housing insert lubricated O-ring 82x2 into flange seal groove and place face seal to protect flange surface.

ATTENTION:

1. ** In all brakes, friction disks and separators should be lubricated. Space is filled with 50 ÷ 120 cm³ mineral oil HLP (DIN 51524) or HM (ISO 6743/4).
 2. Hydraulic brake is delivered without oil (it is lubricated only).
- ** For LB/288 fill oil after hydraulic motor assembly.

Table 1

Brake type	Steel disk	Sinter disk	Support ring	Opening Pressure		Static torque
				min	max	
				PSI [bar]		
LB/288-7	3	2	4	58÷116 [4÷8]	4350 [300]	531÷708 [6÷8]
LB/288-14	3	2	4	116÷232 [8÷16]	4350 [300]	1150÷1327 [13÷15]
LB/288-21 LBS/289-21 LBS/290-21	3	2	4	246÷333 [17÷23]	4350 [300]	1770÷1947 [20÷22]
LB/288-32 LBS/289-32 LBS/290-32	4	3	3	246÷333 [17÷23]	4350 [300]	2743÷3009 [31÷34]
LB/288-43 LBS/289-43 LBS/290-43	5	4	2	246÷333 [17÷23]	4350 [300]	3628÷3982 [41÷45]
LB/288-63 LBS/289-63 LBS/290-63	7	6	-	246÷333 [17÷23]	4350 [300]	5310÷5753 [60÷65]



Item Pos.Nr.	Part to remove Zerlegbare Teile	C o m m e n t s B e s c h r e i b u n g
11	Castellated Nut	On tapered shaft motors only. Remove it by S=46 mm socket spanner or unscrew it manually. ***
	Kronenmutter	<u>Nur für Motoren mit Keilwellen.</u> Die Mutter mit Hand oder mittels Steckschlüssels S=46 mm lösen.
12	Washer	Take it out along the brake shaft. ***
	Scheibe	Entlang der Bremswelle herausnehmen.
9	Parallel Key	Take it out using a little chisel and a plastic hammer. Knock the parallel key slightly several times (along the brake shaft) on the front side. ***
	Paßfeder	Mit einem Meißel und Kunststoffhammers die Paßfeder herausschlagen. Auf der Stirnfläche der Paßfeder entlang der Bremsachse schlagen.
6, 4, 30, 5, 29	Seal Plug G 1/4, Plug G 3/8, Plug G 1/4, Washer 17x21, Washer 13x17	Place the brake with the output shaft downwards directed in assembly fixture (plate with central hole ø126 for LBS(LBV)/314 or ø161 for LBS(LBV)/315 with two pins opposite staved into it). Unscrew seal plug using a socket spanner or manually. Plug G 3/8 is unscrewed by an Allen head spanner S=19 mm; plug G 1/4 is screwed by an Allen head spanner S=6 mm. Place parts in order aside. *** Die Bremse mit der Ausgangswelle nach unten im Haltewerkzeug spannen (Halteplate mit Zentrierbohrung ø126 für LBS(LBV)/314 oder ø161 für LBS(LBV)/315 mit zwei gegenüber eingeschlagenen Stiften). Stopfen G 3/8 wird mit Steckschlüssel S=19 mm und Stopfen G 1/4 mit Steckschlüssel S=17 mm losgeschraubt. Die Teile seitwärts ordnen.
	Stopfen G 1/4, Stopfen G 3/8, Stopfen G 1/4, Dichtring 17x21, Dichtring 13x17	
35	Safety Cap	Remove it manually or by screwdriver. ***
	Stützkappe	Mit Hand oder Schraubenzieher entfernen.
31, 32	Washer Ring A90,	Take out retaining ring using pliers for holes. Remove washer. ***
	Scheibe Ring A90,	Den Ring mit Zange für Bohrungen ausziehen. Die Scheibe entfernen.
33	Screw M10 (8 pcs.)	Unscrew them by a S8 Allen head spanner. ATTENTION: Valid for last two screws: unscrew them uniformly, diametrically, successively to avoid breaking the screw heads which can be caused by spring pressure. ***
	Zylinderschrauben M10 (8 St.)	Die Schrauben mittels Steckschlüssels S=8 mm lösen. ACHTUNG: Geltend für die letzten zwei Schrauben: diese langsam, kreuzweise losschrauben, um Zerreissen der Schraubenköpfe infolge Federpresskraft zu vermeiden.
26	Flange	Take it out upwards incl. shaft seal ring, item 7 and bearing, item 25 using two screwdrivers. ***
	Flansch	Den Flansch, inkl. Wellendichtring, Pos.7 und Lager, Pos.25 nach oben herausziehen. Dafür zwei Schraubenzieher verwenden.

Item Pos.Nr.	Part to remove Zerlegbare Teile	Comments Beschreibung
25	Bearing	Place the flange on a plate with hole min. ø95 as flange face to be leaned on plate. Knock out the bearing by assembly bushing with external diameter max.ø58 and a plastic hammer from opposite side. ***
	Lager	Den Flansch auf Platte mit Bohrung min. ø95 stellen, so daß seine Stirnfläche die Platte berührt. Den Lager mit Hülse (Außendiameter max.ø58) und Kunststoffhammer von der Gegenseite ausschlagen.
24	Shaft Seal	Knock out the shaft seal ring using a bushing with with external diameter ø 71 and a plastic hammer. ***
	Wellendichtring	Den Wellendichtring mit einer Hülse mit Außendiameter ø 71 und Kunststoffhammer ausschlagen.
23	O-ring	Take it out of its seat in the Flange. ***
	O-Ring	Den O-Ring aus seinem Sitz im Flansch herausziehen.
22, 34	Springs	Remove the springs consequetively out of their seats in balance plate. ***
	Kraftfeder	Die Feder nacheinander aus Kolben entfernen.
20	Balance Plate	Take the balance plate out of brake housing, using two screws M6x20, screwed in advance in M6 holes to rest and using puller. Use slight swivelling motions ***
	Kolben	In der Bohrungen M6 des Kolbens zwei Schrauben M6x20 bis zum Anschlag einschrauben. Den Kolben dann mit Abzieher und leichten Drehebewegungen herausnehmen.
21	Washers	Turn balance plate with spring holes downwards and spring washers will drop out. ***
	Scheiben	Den Kolben mit den Federlöchern nach unten kippen, damit die Scheiben herausfallen.
16, 18, 17, 19	Thrust Ring, O-ring	Take them out of the balance plate housing. ***
	Stützring, O-ring	Die O-Ringe aus den Kolbennuten herausziehen.
10, 14, 15, 13, 8	Shaft, Sinterdiscs, Lamelles, Locking Bushing, Bearing	Take the complete unit (consisting of shaft, bearing bushing staved on it and roller-retainer ring, 6 pcs. sinterdiscs with internal teeth, 7 pcs. lamelles and locking bushing) out of housing. Pull the bearing out by puller. Order friction elemnts pack aside for testing defects. (availability of wear and weight checking). ***
	Welle, Sinterlamellen, Lamellen, Rastbuchse, Lager	Die komplette Baugruppe, bestehend aus Welle, Lagerhülse und Lagerkäfig, 6 St.Sternlamellen, 7 St.Lamellen und Rastbuchse aus Gehäse entfernen. Die Lager mittels Abziehers herausziehen. Die Friktions-elemente auf Verschleiß prüfen und das Gewicht kontrolieren.
3, 7, 2,	Housing, Shaft Seal Ring, Retaining Ring,	Place housing with flange upwards on surface. Open retaining ring and take it out by pliers for holes. Pull shaft seal ring out of its seat by bushing and plastic hammer. Dismantling of bearing external race is not allowed.

Item Pos.Nr.	Part to remove Zerlegbare Teile	Comments Beschreibung
8	Bearing Gehäuse, Wellendichtring, Sicherungsring, Lager	<p>ATTENTION: For absolute effectiveness it is recommended changing of:</p> <ul style="list-style-type: none"> A) all seal elements; B) lamelles (7 pcs.) and sinterdiscs (6 pcs.) C) springs Item 22 because of material fatigue D) washers Item 21 to reach parameters for separation, engagement and control of static (frictional) moment. <p style="text-align: center;">***</p> <p>Das Gehäuse mit dem Flansch nach oben kippen. Den Sicherungsring mit einer Spezialzange herausziehen. Den Wellendichtring mit einer Buchse und Kunststoffhammer ausschlagen. Die äußere Laufscheibe nicht demontieren.</p> <p>ACHTUNG: Damit die einwandfreie Funktion der Bremse gewährleistet werden kann, empfieilt sich die folgenden Teile zu ersetzen:</p> <ul style="list-style-type: none"> A) Dichtungselemente; B) Lamellen (7 St.) und Sinterlamellen (6 St.); C) Feder, Pos.22 infolge Materialermüdung; D) Scheiben, Pos.21, um die Parameter des Bremseingriffs und -auslösens zu erreichen. Dadurch wird auch das statische (Frikitions-) Bremsmoment kontrolliert.

1. CLEANING: All parts (except the seals) should be washed in a weak solvent on carbon base and then degreased.

2. MEASURING AND REPLACEMENT All parts should be measured and the actual dimensions should be compared with the nominal ones given in the technical documentation. Replace worn out parts with new ones. Replace all rubber and plastic parts.

3. LUBRICATION: Lubricate all parts which should be assembled with grease or Vaseline film.

1. REINIGEN: Alle Teile (ausser Dichtungen) werden mit einem schwachen Lösungsmittel auf Kohlenstoffbasis gereinigt und entfettet.

2. MESSEN UND AUSWECHSELN: Alle Teile werden gemessen, um ihre Konformität mit den in der technischen Dokumentation genannten Abmessungen zu prüfen. Die Verschleißteile auswechseln. Alle Gummi - und Kunststoffteile ersetzen.

3. SCHMIERUNG: Alle einzubauenden Teile nach der Messung mit einer dünnen Schicht Fett oder technischer Vaseline schmieren.

Item Pos.Nr.	Part to mount Montageteile	Comments Beschreibung
3, 8	Housing, Bearing Race Gehäuse, Lageraußenring	<p>Stave external bearing race on front tapered bearing (with the bigger diameter to the housing cavity) by bushing made from non-ferous metal (bronze, brass) with sizes $\varnothing 80 \times \varnothing 94 \times 50$ and 2.000 daN press. Place the part with internal cavity upwards on mounting/dismantling plate with hole $\varnothing 126$ (for LBS(LBV)/314) or with hole $\varnothing 162$ (for LBS(LBV)/315) and two pins $\varnothing 12$ (for LBS(LBV)/314) or $\varnothing 16$ (for LBS(LBV)/315). ***</p> <p>Mit Hilfe einer Buntmetallbuchse (Bronze, Messing) - $\varnothing 80 \times \varnothing 94 \times 50$ und einer Presse 2.000 daN den Lageraußenring des vorderen Kegelrollenlagers (mit dem größeren Durchmessers zur Gehäuseaushölung gerichtet) einschlagen. Den Teil mit der Aushölung nach oben in einer Montageplatte mit Bohrung $\varnothing 126$ (für LBS(LBV)/314) oder $\varnothing 162$ (für LBS(LBV)/315) und zwei Stiften $\varnothing 12$ (für LBS(LBV)/314) oder $\varnothing 16$ (für LBS(LBV)/315) befestigen.</p>
2, 7	Retainig Ring Shaft Seal (5bar) Sicherungsring, Wellendichtring	<p>Place retaining ring in housing groove by pliers for holes. Stave the light externally oiled shaft seal ring in its housing seat (oiled) from the internal housing cavity by bushing and plastic hammer. ***</p> <p>Den Sicherungsring in seinem Platz mit Sonderzange im Gehäuse montieren. Den Wellendichtring (leicht geschmiert) von außen mittels Buchse und Kunststoffhammer in seinem Sitz einschlagen.</p>
10, 8, 13, 14, 15	Shaft Bearing, Locking Bushing, Lamelles, Sinterdiscs	<p>Stave the internal bearing race, incl. roller-retainer ring of front tapered bearing to rest. Use 2.000 daN press and bushing $\varnothing 61 \times \varnothing 68 \times 120$. Then carefully order locking bushing and lamelles as starting and finishing the pack with steel discs. Internal teeth of sinterdiscs are engaged with external shaft teeth. Place a slightly oiled safety metal cap (for protecting shaft seal ring "lips" Item 7). Stave the shaft carefully in brake housing to rest).</p> <p>ATTENTION: External 3 teeth of all 7 metal lamelles should correspond to splined housing grooves! ***</p>
	Welle, Lager, Rastbuchse, Lamellen, Sinterlamellen	<p>Lagerhülse und Lagerkäfig des vorderen Kegelrollenlagers bis zum Anschlag auf der Welle einschlagen. Presse 2.000 daN und Buchse $\varnothing 61 \times \varnothing 68 \times 120$ verwenden. Dann die Rasrbuchse und die Lamellen montiere, indem die Reihenfolge der Lamellenmontage einhalten (die Innenzähne der Sinterlamellen greifen in den Außenzähnen der Welle). Auf den Wellenzapfen Schützkappe (leicht geschmiert) legen, um die Lippen der Dichtung, Pos.7 vom Brechen zu schützen. Die Welle vorsichtig bis zum Anschlag im Gehäuse einbringen.</p> <p>ACHTUNG: Die 3 Außenzähne der sieben Stahllamellen sollen mit den gefrästen Nuten in Eingriff sein!</p>
16, 18, 17, 19	O-rings, Thrust Rings,	<p>Assemble consequitively well oiled O-rings and thrust rings. O-rings should fit well in well oiled arc-shaped parts of thrust rings. Place them in grooves from their external face of balance plate. ***</p>

Item Pos.Nr.	Part to mount Montageteile	Comments Beschreibung
	O-Ringe, Stützring	Die geschmierten O-Ringe und den Stützring in den Kolbennuten nacheinander einbauen. Die O-Ringe gehen in den bogenförmigen Bereich des Stützringes hinein. Die Stützringe in den Nuten von der Fase her montieren.
20	Balance Plate	Slightly oil housing cylindrical and balance plate surfaces. Insert balance plate with rings in housing by carefully knocking. ***
	Kolben	Die Zylinderflächen im Gehäuse und Kolben schmieren und den Kolben mit den bereits eingebauten Dichtungen leicht schlagend im Gehüuse einbringen.
21, 22	Washers, Springs	Assemble the necessary number of springs to reach a static (frictional) moment access, (see Application 1). ATTENTION: Washers with width 0,3; 0,5 and 0,8 (Item 21) are assembled only if the static (frictional) moment and pressure of separation are lower than the pointed out in Application 1. *** Scheibe, Feder
		Im Kolben die gewünschte Zahl Feder (um das statische Bremsmoment zu erreichen) hineinbringen, Anhang 1. ACHTUNG: Die Scheiben, Pos.21 (Breite 0,3, 0,5 und 0,8 mm dann montieren, wenn das Bremsmoment und die Öffnungs- und Schleßdruck niedriger als die im Anhang 1 angegebenen !
23, 26, 24, 33	O-ring, Flange, Shaft Seal Ring, Screwes M10	Place the O-ring (oiled in advance) in flange slot. Stave shaft seal ring to rest into the internal flange socket using a relevant bushing or plastic hammer. (External surface of shaft seal ring and flange socket are oiled in advance). Orient flange with rivet holes towards the name plate, Item 28 to the axis of assembling position and the inlet port of the brakes. The four holes have to be positioned at 11° left to it. Screw the eight screws into the holes uniformly, diametrically and consequitively by a socket wrench with tightening torque of 6 ÷ 6,5 daNm. ***
	O-Ring, Flansch, Wellendichtring, Schrauben M10	Den vorgeschmierten O-Ring in Flanschnute einbringen. Im inneren Sitz des Flansches den Wellendichtring mittels Buchse und Kunststoffhammer bis zum Anschlag einschlagen. Wellendichtring und Sitz vorschmieren. Den Flansch wie folgt orientieren: zu den Typenschlitzlöchern (Pos.28). Die 4 Bohrungen befinden sich in 11° links vom Flansch gegenüber der Montageposition und Zuführleitung der Bremse. Dann die 8 St.Schrauben gleichmäßig kreuzweise mit Steckschlüssel S=8 mm und Anzugsmoment 6 ÷ 6,5 daNm festziehen.
25, 31, 32	Bearing, Washer, Ring A90	Mount on shaft the bearing internal ring with separator by bushing ø65xø56 and hammer to rest. Stave the external bearing ring in flange hole by bushing ø 88 x ø 78. Place a regulating washer on the bearing and then place the ring A90 in flange groove using pliers for safety rings. Check the bearing axial clearance by movement the shaft into its end position usin a measuring device (clearance recommended 0,004 ÷ 0,10 mm).

Item Pos.Nr.	Part to mount Montageteile	Comments Beschreibung
	Lager, Scheibe, RingA90	<p>ATTENTION: Technological assembly should be made in first brake mounting and when setting the real bearing axial clearance as follows: Instead of regulating washer, put an assembly one by which bearing clearance is measured; in this way it is defined the real thickness of regulating washer. Dismantle the assembly washer and finally place the corresponding washer</p> <p style="text-align: center;">***</p> <p>Lagerhülse und Lagerkäfig bis zum Anschlag mittels Buchse ø65xø56 auf Welle einschlagen. Den Außendichtring des Lagers in der Flanschbohrung mit Buchse ø88xø78 einschlagen. Die Scheibe auf Lager einlegen; den Ring A90 mit Sonderzangen in Flanschnuten montieren. Durch Vor- und Rücklauf der Welle in Endlagen den Axialspiel in den Lagern (Istwert 0,04 ÷ 0,10 mm) durch Messuhr prüfen.</p> <p>ACHTUNG: Bei Erstmontage der Bremse und wenn Ist-Axialspiel der Lager festzustellen ist, technologischer Zusammenbau ausführen, uzw.: anstatt der Einstellscheibe, Montagescheibe für Lageraxialspiel einbringen und die eigentliche Dicke der Scheibe feststellen. Die Montagescheibe ausbauen und die jeweilig bestimmte Einstellscheibe montieren</p>
5, 29, 4, 6, 30	Washer, Seal Plugs, Plugs	<p>Place washers into the relevant housing and flange holes and screw seal plugs as follows:</p> <p>2 pcs. G $\frac{3}{8}$ - use S=19 mm socket spanner and torque 2,5÷3 daNm;</p> <p>3 pcs. G $\frac{1}{4}$ (4 pcs. for LBV/...) Allen head spanner S=6 mm and torque 2÷2,3 daNm.</p> <p>Screw 2 pcs.seal plugs manually.</p> <p style="text-align: center;">***</p>
	Scheibe, Stopfen	<p>Die Scheiben in den entsprechenden Gehäuse- und Flanschbohrungen einbringen und die Stopfen anziehen:</p> <p>2 St. G $\frac{3}{8}$ - mit Steckschlüssel S=19 mm und Anzugsmoment 2,5÷3 daNm;</p> <p>3 St.G $\frac{1}{4}$ (4 St. für LBV/...) - mit Steckschlüssel S=6 mm und Anzugsmoment 2÷2,3 daNm.</p> <p>Die zwei Stopfen mit Hand festziehen.</p>
9	Parallel Key	<p>Place it on shaf by knocking with plastic hammer.</p> <p style="text-align: center;">***</p>
	Paßfeder	<p>Die Paßfeder mit Kunststoffhammer auf Welle einsschlagen.</p>
1, 35	Safety cap	<p>Mount them on spigot ends</p> <p style="text-align: center;">***</p>
	Schützkappe	<p>An Wellenzapfen montieren.</p>

**Appendix 1
Anhang 1**

Brake Bremse	Spring/Feder item/Pos.22 pcs./St.	Spring/Feder item/Pos.34 pcs./St.	Opening Pressure* Öffnungsdruck*		Static torque Statisches Drehmoment daNm
			min	max	
	59113 604 00	59113 605 00	bar		
LBS(LBV)/... - 21	-	9	4÷5	300	18÷23
LBS(LBV)/... - 29	-	12	6÷7	300	28÷33
LBS(LBV)/... - 43	6	-	9÷10	300	42÷46
LBS(LBV)/... - 65	9	-	13÷15	300	61÷70
LBS(LBV)/... - 85	12	-	18÷20	300	83÷92
LBS(LBV)/... - 110	15	-	20÷25	300	108÷118
LBS(LBV)/... - 130	18	-	27÷29	300	126÷136

* These values indicate the differences between brake inlet pressure and drainage cavities pressure.
Diese Werte bezeichnen die Differenzen zwischen Zufahrdruck der Bremse und Dränageräumen.

ATTENTION:

1. In all brakes, friction discs and separators should be lubricated. Space is filled with 150 ÷ 300 cm³ mineral oil HLP (DIN 51524) or HM (ISO 6743/4).
2. Hydraulic brake is delivered without oil (it is lubricated only).

ACHTUNG:

1. Für einwandfreie Funktion aller Bremsen sind die Reibscheiben und Lamellen zu schmieren. Den Raum mit 150 ÷ 300 cm³ Mineralöl HLP (DIN 51524) or HM (ISO 6743/4) füllen.
2. Die Bremse wird ohne Oil geliefert.